


Five Minute Bot


1





2









OR





You can use the NXT with either AA batteries or the NXT Rechargeable Battery Pack.








4











6



Use two medium length wires to connect the two drive motors to ports **B** and **C** on the NXT.

Important: Make sure that port B gets wired to the motor on the B side, and C to the motor on the C side.

